

EDU 100 Operating Instructions



Using the stereo 3.5mm jack to jack lead supplied, connect either of the external display sockets on the EDU 100, to the external display socket on the bingo machine.

Connect the power supply and switch on at the mains.

Additional display units can be connected together using the other external display socket on the EDU 100.

Ensure that the bingo machine to which EDU 100 is connected, is also connected to the mains.

EDU 100 is supplied complete with power supply and connecting lead.

Power Supply.

Regulated 9 volts d.c. 350 mA. Polarity: Centre Negative.

Note: **Do not use an unregulated power supply.**
 Do not use a power supply greater than 9 volts d.c.